

FREQUENZLISTE

FREQUENCY LIST | LISTE DE FRÉQUENCES | LISTA DE FRECUENCIAS
WYKAZ CZĘSTOTLIWOŚCI | ELENCO DELLE FREQUENZE



WIRELESS MICROPHONES

LDU304.7

470-490 MHz

Group 1	
Channel 1	470.775
Channel 2	473.550
Channel 3	474.075
Channel 4	475.200
Channel 5	476.550
Channel 6	481.050
Channel 7	483.375
Channel 8	485.100
Channel 9	486.000
Channel 10	486.440
Channel 11	487.325
Channel 12	488.925

LDU305.1

514-542 MHz

Group 1	
Channel 1	514.275
Channel 2	515.850
Channel 3	518.700
Channel 4	523.350
Channel 5	524.250
Channel 6	525.750
Channel 7	529.350
Channel 8	533.625
Channel 9	536.700
Channel 10	539.100
Channel 11	540.750
Channel 12	541.800

LDU305

584-607 MHz

Group 1	
Channel 1	584.400
Channel 2	587.500
Channel 3	589.575
Channel 4	591.050
Channel 5	593.425
Channel 6	595.200
Channel 7	598.450
Channel 8	599.650
Channel 9	601.275
Channel 10	603.775
Channel 11	605.500
Channel 12	606.750

LDU306

655-679 MHz

Group 1	
Channel 1	655.400
Channel 2	658.500
Channel 3	660.575
Channel 4	662.050
Channel 5	664.425
Channel 6	666.200
Channel 7	669.450
Channel 8	670.650
Channel 9	672.275
Channel 10	674.775
Channel 11	676.500
Channel 12	677.750

LDU308

823-832, 863-865 MHz

Group 1	
Channel 1	863.100
Channel 2	863.500
Channel 3	864.300
Channel 4	864.900
Channel 5	823.100
Channel 6	823.500
Channel 7	824.100
Channel 8	825.500
Channel 9	826.300
Channel 10	828.900
Channel 11	830.100
Channel 12	831.900