

# FREQUENCY LIST

FREQUENZLISTE | LISTE DE FRÉQUENCES | LISTA DE FRECUENCIAS  
WYKAZ CZĘSTOTLIWOŚCI | ELENCO DELLE FREQUENZE



## WIRELESS MICROPHONES

### LDU505

584 - 607 MHz

	Ch. 1	Ch. 2	Ch. 3	Ch. 4	Ch. 5	Ch. 6	Ch. 7	Ch. 8	Ch. 9	Ch. 10	Ch. 11	Ch. 12
Group 1:	584.400	587.500	589.575	591.050	593.425	595.200	598.450	599.650	601.275	603.775	605.500	606.750
Group 2:	585.250	586.500	588.225	590.725	592.350	593.550	597.800	598.575	600.950	602.425	604.500	607.600
Group 3:	584.200	585.675	586.800	588.450	589.750	592.200	594.325	598.225	600.525	602.575	605.600	607.575
Group 4:	585.775	586.500	590.200	591.600	592.700	594.250	595.500	599.100	601.425	603.450	604.775	606.900
Group 5:	585.100	587.225	588.550	590.575	592.900	596.500	597.750	599.300	600.400	601.800	603.500	606.225
Group 6:	584.425	586.400	589.425	591.475	593.775	597.675	599.800	602.250	603.550	605.200	606.325	607.800
Group 7:	584.700	587.800	589.875	591.350	593.725	595.500	598.750	599.950	601.575	604.075	605.800	607.050
Group 8:	585.550	586.800	588.525	591.025	592.650	593.850	598.100	598.875	601.250	602.725	604.800	607.900
Group 9:	584.500	585.975	587.100	588.750	590.050	592.500	594.525	598.525	600.825	602.875	605.900	607.875
Group 10:	586.075	586.800	590.500	591.900	593.000	594.550	595.800	599.400	601.725	603.750	605.075	607.200

### LDU506

655 - 679 MHz

	Ch. 1	Ch. 2	Ch. 3	Ch. 4	Ch. 5	Ch. 6	Ch. 7	Ch. 8	Ch. 9	Ch. 10	Ch. 11	Ch. 12
Group 1:	655.400	658.500	660.575	662.050	664.425	666.200	669.450	670.650	672.275	674.775	676.500	677.750
Group 2:	656.250	657.500	659.225	661.725	663.350	664.550	667.800	669.575	671.950	673.425	675.500	678.600
Group 3:	655.200	656.675	657.800	659.450	660.750	663.200	665.325	669.225	671.525	673.575	676.600	678.575
Group 4:	656.775	659.500	661.200	662.600	663.700	665.250	666.500	670.100	672.425	674.450	675.775	677.900
Group 5:	656.100	657.225	659.550	661.575	663.900	667.500	668.750	670.300	671.400	672.800	674.500	677.225
Group 6:	655.425	657.400	660.425	662.475	664.775	668.675	670.800	673.250	674.550	676.200	677.325	678.800
Group 7:	655.700	658.800	660.875	662.350	664.725	666.500	669.750	670.950	672.575	675.075	676.800	678.050
Group 8:	656.550	657.800	659.825	662.025	663.650	664.850	668.100	669.875	672.250	673.725	675.800	678.900
Group 9:	655.500	656.975	658.100	659.750	660.050	663.500	665.525	669.525	671.825	673.875	676.900	678.875
Group 10:	657.075	659.800	661.500	662.900	664.000	665.550	666.800	670.400	672.725	674.750	676.075	678.200

## FREQUENCY LIST

FREQUENZLISTE | LISTE DE FRÉQUENCES | LISTA DE FREQUENCIAS  
WYKAZ CZĘSTOTLIWOŚCI | ELENCO DELLE FREQUENZE



## WIRELESS MICROPHONES

### LDU506UK

606 - 614 MHz

	Group 1	Group 2	Group 3	Group 4
Channel 1:	606.600	606.000	606.300	606.900
Channel 2:	607.500	606.400	606.800	607.400
Channel 3:	608.150	607.050	607.350	608.550
Channel 4:	609.150	607.850	607.750	609.200
Channel 5:	609.950	608.300	608.500	609.900
Channel 6:	610.550	609.100	609.850	610.650
Channel 7:	611.250	609.500	610.450	611.950
Channel 8:	612.300	611.450	610.750	612.350
Channel 9:	613.150	613.300	611.850	613.200
Channel 10:	613.500	613.600	612.600	613.800

### LDU508

823 - 832 / 863 - 865 MHz

	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8
Channel 1:	863.100	863.100	863.200	863.150	863.150	863.100	863.250	863.250
Channel 2:	863.500	863.500	863.700	863.550	863.950	863.700	863.250	863.850
Channel 3:	864.300	864.000	864.100	864.050	864.450	864.500	864.150	864.350
Channel 4:	864.900	864.800	864.800	864.850	864.850	864.900	864.750	864.750
Channel 5:	823.100	823.100	823.200	823.150	823.100	823.100	823.150	823.250
Channel 6:	823.500	823.700	823.800	823.750	823.700	823.600	823.850	823.950
Channel 7:	824.100	824.700	824.600	824.750	824.700	824.600	824.850	824.950
Channel 8:	825.500	825.800	825.600	825.850	825.800	825.300	825.650	825.750
Channel 9:	826.300	826.500	826.800	826.550	826.500	826.200	826.850	826.950
Channel 10:	828.900	827.700	828.100	827.750	827.700	827.300	828.250	828.350
Channel 11:	830.100	829.100	829.600	829.150	829.100	829.200	829.550	829.650
Channel 12:	831.900	830.600	831.300	831.650	830.600	831.600	831.150	831.250

## FREQUENCY LIST

FREQUENZLISTE | LISTE DE FRÉQUENCES | LISTA DE FRECUENCIAS  
WYKAZ CZĘSTOTLIWOŚCI | ELENCO DELLE FREQUENZE



## WIRELESS MICROPHONES

### LDU518

1785 - 1800 MHz

	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8	Group 9	Group 10
Channel 1:	1.795.650	1.795.050	1.785.500	1.795.100	1.795.100	1.785.150	1.799.850	1.785.200	1.799.800	1.795.250
Channel 2:	1.796.050	1.795.450	1.785.950	1.795.500	1.795.950	1.785.550	1.799.450	1.785.600	1.799.400	1.795.850
Channel 3:	1.796.750	1.796.150	1.786.850	1.796.350	1.797.250	1.786.400	1.798.600	1.786.450	1.798.550	1.796.350
Channel 4:	1.797.250	1.797.100	1.787.250	1.796.850	1.797.700	1.786.900	1.798.100	1.786.950	1.798.050	1.797.300
Channel 5:	1.797.650	1.797.500	1.788.100	1.797.700	1.798.650	1.787.750	1.797.250	1.787.800	1.797.200	1.797.750
Channel 6:	1.799.000	1.798.350	1.788.650	1.798.100	1.799.100	1.795.850	1.795.850	1.788.200	1.795.800	1.798.650
Channel 7:	1.799.400	1.798.950	1.789.500	1.799.500	1.785.100	1.796.250	1.795.450	1.795.950	1.795.400	1.799.050
Channel 8:	1.785.700	1.799.350	1.789.950	1.795.950	1.785.500	1.797.200	1.793.950	1.796.700	1.794.350	1.799.900
Channel 9:	1.786.100	1.785.100	1.790.550	1.797.250	1.786.350	1.797.950	1.793.550	1.797.650	1.793.500	1.796.900
Channel 10:	1.786.950	1.785.500	1.791.000	1.798.650	1.786.850	1.798.400	1.792.650	1.798.500	1.793.000	1.798.150
Channel 11:	1.787.450	1.786.350	1.791.900	1.799.100	1.788.100	1.799.050	1.792.200	1.798.900	1.792.150	1.799.500
Channel 12:	1.788.300	1.786.850	1.793.150	1.799.650	1.789.100	1.799.450	1.790.750	1.799.450	1.791.750	1.799.950

### LDU518

1785 - 1800 MHz

	Group 11	Group 12	Group 13	Group 14	Group 15	Group 16	Group 17	Group 18	Group 19	Group 20
Channel 1:	1.785.150	1.794.050	1.795.350	1.799.050	1.785.500	1.785.250	1.785.450	1.795.150	1.799.900	1.785.100
Channel 2:	1.785.800	1.793.150	1.795.750	1.798.600	1.786.050	1.785.650	1.785.900	1.795.550	1.799.500	1.785.500
Channel 3:	1.786.250	1.792.750	1.796.900	1.798.050	1.786.500	1.786.500	1.786.900	1.796.400	1.798.150	1.786.350
Channel 4:	1.786.800	1.791.900	1.797.300	1.797.600	1.787.400	1.787.000	1.787.350	1.796.900	1.797.300	1.786.850
Channel 5:	1.787.250	1.791.350	1.798.150	1.796.700	1.787.850	1.788.250	1.788.250	1.797.750	1.796.900	1.787.700
Channel 6:	1.788.100	1.790.500	1.798.650	1.796.250	1.788.550	1.789.650	1.788.700	1.798.150	1.795.900	1.788.100
Channel 7:	1.788.600	1.790.050	1.799.500	1.795.550	1.788.950	1.790.100	1.789.400	1.799.550	1.795.500	1.798.500
Channel 8:	1.790.050	1.789.450	1.799.900	1.795.150	1.795.900	1.790.700	1.796.200	1.796.000	1.796.350	1.790.550
Channel 9:	1.790.500	1.789.000	1.796.350	1.793.750	1.796.750	1.797.650	1.796.750	1.797.300	1.797.750	1.791.000
Channel 10:	1.791.900	1.788.100	1.797.750	1.793.250	1.797.150	1.798.100	1.797.600	1.798.700	1.798.650	1.791.900
Channel 11:	1.792.750	1.787.700	1.799.050	1.792.850	1.798.050	1.798.700	1.799.350	1.799.150	1.799.050	1.792.300
Channel 12:	1.793.150	1.786.550	1.799.450	1.791.100	1.798.500	1.799.100	1.799.750	1.799.650	1.799.750	x

## FREQUENCY LIST

FREQUENZLISTE | LISTE DE FRÉQUENCES | LISTA DE FRECUENCIAS  
WYKAZ CZĘSTOTLIWOŚCI | ELENCO DELLE FREQUENZE



## WIRELESS MICROPHONES

### LDU505CS4

554 - 586 MHz

	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8	Group 9	Group 10
Channel 1	583,475	585,575	584,500	584,675	584,400	584,825	583,350	584,675	585,375	584,400
Channel 2	583,075	584,850	578,125	582,600	582,350	579,125	581,600	582,600	584,500	582,350
Channel 3	582,450	559,600	571,450	579,400	581,475	578,625	573,825	581,750	581,150	581,475
Channel 4	581,625	558,975	565,600	571,600	579,125	574,475	572,800	579,400	580,600	579,125
Channel 5	580,500	557,750	564,975	570,975	577,600	567,550	571,550	578,375	579,200	578,100
Channel 6	579,575	557,025	564,150	570,150	576,975	566,000	570,775	577,150	578,125	577,100
Channel 7	578,350	555,675	563,025	569,750	576,150	561,100	569,050	576,650	577,450	576,375
Channel 8		554,650	561,675	569,025	575,025	557,075	565,700	575,300	576,100	575,850
Channel 9			560,125	567,675	573,675	555,300	561,075	574,450	575,250	574,825
Channel 10				566,125	572,125			571,450	572,250	573,475
Channel 11								564,700	565,500	572,850
Channel 12								562,600	563,400	570,050
Channel 13								561,050	561,850	564,525
Channel 14								556,275	557,075	562,450
Channel 15									554,250	560,575

### LDU506CS4

662 - 694 MHz

Channel	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6	Group 7	Group 8	Group 9	Group 10
Channel 1	662,300	670,500	666,025	667,250	662,100	667,325	664,275	665,750	663,050	662,275
Channel 2	668,700	678,100	666,775	672,500	668,500	668,775	665,500	671,750	664,050	663,450
Channel 3	669,500	666,975	668,000	673,750	672,775	669,700	668,125	672,500	664,775	672,575
Channel 4	664,975	669,300	682,025	662,750	661,700	673,450	669,575	675,250	668,025	673,300
Channel 5	672,225	670,100	685,500	664,500	666,225	676,275	670,500	676,250	675,025	670,900
Channel 6	682,775	672,775	688,225	666,500	666,975	671,700	674,250	662,750	662,400	675,275
Channel 7	685,100	680,775	692,000	671,500	669,300	668,300	677,075	663,500	677,625	676,975
Channel 8	686,300	682,975	692,700	674,500	669,700	684,700	672,500	665,250	684,200	661,400
Channel 9	680,975	684,900	693,100	679,250	682,225	691,450	669,100	667,500	688,025	676,450
Channel 10	685,900	686,500	693,900	679,750	685,700	681,050	685,500	671,250	688,475	691,500
Channel 11	687,000	692,900	680,225	681,250	686,100	692,750	692,250	674,500	689,650	692,325
Channel 12	692,700	693,700	680,975	683,750	680,025	681,950	681,850	682,500	693,700	693,750
Channel 13	693,900	684,500	684,700	687,500	681,500	685,525	682,750	684,250	694,250	679,925
Channel 14		692,500	685,900	692,250	690,975	686,575	686,325	687,500	679,325	680,925
Channel 15				684,250	692,900	690,775	687,375	691,750	690,350	684,100
Channel 16				689,750	694,100	682,600	691,575	688,500	682,950	687,500
Channel 17				691,750		689,425	683,400	689,250	692,425	689,650
Channel 18							690,225	691,250	680,600	

## FREQUENCY LIST

FREQUENZLISTE | LISTE DE FRÉQUENCES | LISTA DE FRECUENCIAS  
WYKAZ CZĘSTOTLIWOŚCI | ELENCO DELLE FREQUENZE



## WIRELESS MICROPHONES

### LDU508CS4

823 - 832 / 863 - 865 MHz

	Group 1	Group 2	Group 3	Group 4	Group 5	Group 6
Channel 1	824,500	823,250	826,225	824,025	824,975	823,000
Channel 2	825,750	823,750	826,975	826,225	828,000	824,225
Channel 3	827,250	826,500	828,500	826,975	828,700	828,000
Channel 4	828,250	827,500	828,900	829,300	829,100	829,100
Channel 5	823,500	828,250	863,150	829,700	826,025	829,500
Channel 6	863,150	825,250	863,550	863,125	863,150	824,975
Channel 7	863,550	863,125	864,175	863,525	863,550	863,125
Channel 8	864,175	863,525	864,600	864,175	864,175	863,525
Channel 9	864,600	864,175		864,625	864,600	864,175
Channel 10		864,625				864,625